



## COTTON CANDY OPERATING INSTRUCTIONS

Be sure equipment is connected to properly grounded 120 volt power supply with 15 amp circuit (230 volts for export models).

### OPERATION:

- 1) Loosen the two shipping travel knobs. These are the knurled knobs on either side of the motor cover, below the head.
- 2) Press the **MOTOR** switch to the "ON" position.
- 3) Fill the spinner head with the desired amount of floss sugar. Never fill the head past the bottom level of the filler spout. (Note: For best results, keep the spinner head full)
- 4) Press the **HEAT** switch to the "ON" position.
- 5) Turn the **HEAT CONTROL** knob to heat setting **HIGH**
- 6) Once the floss starts to flow out of the head, reduce the **HEAT CONTROL** to the green range as indicated on the **METER**. (Note: High setting can cause cutting of the floss and potentially clog the screen assembly.)
- 7) When the amount of floss that is being produced starts to slow, add more sugar. **DO NOT** adjust the **HEAT CONTROL** knob setting.
- 8) The typical operating setting on the **HEAT CONTROL** knob is in the green range on the **METER**. This will vary due to fluctuations in environmental situations.

### SHUTTING DOWN:

- 1) Press the **HEAT** switch to the "**OFF**" position.
- 2) Wait 3-5 minutes for the spinner head to cool down.
- 3) Press the **MOTOR** switch to the "**OFF**" position.
- 4) For end of day procedures, operate the machine until the remaining floss sugar in the head is gone, and then do steps 1-3.
- 5) **IF THE MACHINE IS TO BE MOVED**, re-tighten the two shipping travel knobs to prevent damage to the head during transit. (Note: Some smoking may appear as the head is running out of sugar. This is normal and will clean any residual sugar from the screen.)

**IN CASE OF A MALFUNCTION: IMMEDIATELY SHUT-OFF THE MOTOR AND HEAT SWITCHES AND CORRECT THE PROBLEM.**