

The Party Corner

19 E. Newman Springs Rd. Shrewsbury, N.J. 07702
732-741-0040 Fax: 732-747-1589

www.partycorner.com

Email: info@partycorner.com

“So many reasons to party....but only one place to shop!”
Since 1969, serving all your party and event rental needs.

OPERATING INSTRUCTIONS CHAFING DISHES AND URNS

1. Do not use anything but STERNO TYPE FUEL in the burner.
2. NEVER light the burner unit before putting liquid into the water pan, urn, or kettle body. Low flame is sufficient to maintain proper heat.
3. Do not put unit on a hot stove or an open flame
4. Stainless steel food pans can be used for cooking. They can also be placed in the over the keep food hot.
5. Chafing dish water pans should be filled with hot water. Check water pan when in use to insure sufficient water is contained at all times. DON NOT USE WITHOUT WATER.
6. Pry lid off of sterno and set sterno container under water pan. Light sterno with long match or grill lighter. One can of sterno should last between 2 to 2 ½ hours.
7. To extinguish sterno, simply place sterno lid back over flame.

We suggest you use an underliner tray with items using burner to protect your linen and/or serving surface.

CLEANING INSTRUCTIONS

Before returning chafing dish, scrape and wash food pans. Wash chafing dish and urns in lukewarm water and mild detergent. NEVER USE HARSH ABRASIVES.

REMEMBER

You are renting this equipment. Be sure you are aware of the terms of your rental contract. Always return your chafing dish or urn clean to avoid additional cleaning charges.

