

The Party Corner

19 E. Newman Springs Rd. Shrewsbury, N.J. 07702
732-741-0040 Fax: 732-747-1589

www.partycorner.com

Email: partycorner@msn.com

“So many reasons to party....but only one place to shop!”
Since 1969, serving all your party and event rental needs.

OPERATING INSTRUCTIONS COFFEE MAKERS

Use 12 gauge extension cord only.

- 1) Fill pot with COLD water to desired amount (pump stick needs to be in place when filling with water).
- 2) Add coffee to basket (see equivalents below).
- 3) Plug coffee pot into standard electric outlet.
- 4) When coffee has finished brewing, remove basket. The pot will keep the coffee hot.
- 5) Rinse out coffee pot before returning. NEVER IMMERSE COFFEE POT IN WATER.

Brewing time: It takes approximately ½ hour to brew coffee in 30-60 cup urns – 60 to 90 minutes in 90 – 100 cup urns.

Coffee equivalents:

# of cups	Coffee measure
30	2 cups
55-60	3 ½ cups (or 1 lb.)
90	6 cups

One pound of coffee is equal to approximately 4 ¾ cups of ground coffee.

